

# Si photodiodes

S2387 series

# For visible to IR, general-purpose photometry

- Features	Applications					
→ High sensitivity in visible to infrared range	→ Analytical equipment					

Dow dark current→ Optical measurement equipment, etc.→ High linearity

### **Structure / Absolute maximum ratings**

Type No.	Window material			E.C. 1:	Absolute maximum ratings				
		Package	Photosensitive area size	Effective photosensitive area	Reverse voltage VR max	Operating temperature* Topr	Storage temperature* Tstg		
		(mm)	(mm)	(mm²)	(V)	(°Ċ)	(°C)		
S2387-16R	Resin potting	2.7 × 15	1.1 × 5.9	6.4					
S2387-33R		6 × 7.6		5.7	30	-20 to +60	-20 to +80		
S2387-66R		8.9 × 10.1	5.8 × 5.8	33	30	-20 10 +60	-20 10 +80		
S2387-1010R		15 × 16.5	10 × 10	100					

<sup>\*</sup> No dew condensation


When there is a temperature difference between a product and the surrounding area in high humidity environments, dew condensation may occur on the product surface. Dew condensation on the product may cause deterioration in characteristics and reliability.

Note: Exceeding the absolute maximum ratings even momentarily may cause a drop in product quality. Always be sure to use the product within the absolute maximum ratings.


## **■** Electrical and optical characteristics (Typ. Ta=25 °C, unless otherwise noted)

Type No.	Spectral response range	Peak sensitivity wavelength	S (A/W)		Short circuit current Isc 100 lx		Dark current	coefficient	Rise time tr VR=0 V	Terminal capacitance Ct	Shunt resistance Rsh VR=10 mV		Noise equivalent power NEP	
	λ	λр	λр	GaP LED	He-Ne laser	Min.	Тур.	Max.	TCID	RL=1 kΩ	f=10 kHz	Min.	Тур.	$V_R=0 V$ $\lambda=\lambda p$
	(nm)	(nm)	·	560 nm	633 nm	(µA)	(µA)	(pA)	(times/°C)	(µs)	(pF)	(GΩ)	$(G\Omega)$	(W/Hz <sup>1/2</sup> )
S2387-16R	340 to 1100	340 to 1100 960 0.5	0.58 0.3	0.33	0.37	4.4	6.0	-	1.12	1.8	730	2	50	9.9 × 10 <sup>-16</sup>
S2387-33R						4.4	5.8	,						
S2387-66R				0.55		24	31	50		10	4300	0.2		$2.2 \times 10^{-15}$
S2387-1010R						68	91	200		33	12000	0.05	5	$3.1 \times 10^{-15}$

## Spectral response




## - Photosensitivity temperature characteristic



KSPDB0058EC

# Dark current vs. reverse voltage




KSPDB0117ED

#### Dimensional outlines (unit: mm)

# S2387-16R Hole $(2 \times) \phi 0.8$ + $2 \times 2 \times 3 \times 4$ Photosensitive area $1.1 \times 5.9$

# Photosensitive surface






②⊶★⊸①


The resin potting may extend a maximum of 0.1 mm above the upper surface of the package.


KSPDA0106E

#### S2387-33R



# Photosensitive







The resin potting may extend a maximum of 0.1 mm above the upper surface of the package.


KSPDA0108FI

#### S2387-66R



# Photosensitive








The resin potting may extend a maximum of 0.1 mm above the upper surface of the package.

VCDD A0110ED

#### S2387-1010R







The resin potting may extend a maximum of 0.1 mm above the upper surface of the package.

KSPDA0112EB



## Si photodiodes

#### S2387 series

#### Recommended soldering conditions

Solder temperature: 260 °C (5 s or less, once)

Solder the leads at a point at least 2 mm away from the package body.

Note: When you set soldering conditions, check that problems do not occur in the product by testing out the conditions in advance.

#### Related information

www.hamamatsu.com/sp/ssd/doc\_en.html

- Precautions
- · Disclaimer
- · Metal, ceramic, plastic package products
- Technical note
- · Si photodiodes

Information described in this material is current as of July 2022.

Product specifications are subject to change without prior notice due to improvements or other reasons. This document has been carefully prepared and the information contained is believed to be accurate. In rare cases, however, there may be inaccuracies such as text errors. Before using these products, always contact us for the delivery specification sheet to check the latest specifications.

The product warranty is valid for one year after delivery and is limited to product repair or replacement for defects discovered and reported to us within that one year period. However, even if within the warranty period we accept absolutely no liability for any loss caused by natural disasters or improper product use. Copying or reprinting the contents described in this material in whole or in part is prohibited without our prior permission.

# AMAMATSU

www.hamamatsu.com

HAMAMATSU PHOTONICS K.K., Solid State Division

1126-1 Ichino-cho, Higashi-ku, Hamamatsu City, 435-8558 Japan, Telephone: (81)53-434-3311, Fax: (81)53-434-5184

1126-1 ICNINO-CRO, HigasRin-Ku, Hamamatsu City, 435-8558 Japati, Ielepinuie: (0.1)53-47-3311, Fax. (0.1)53-47-3311, IGA. (0.1)53-47-3311, IGA. (0.1)54-17-3311, IGA. (0.1)54-17-